


KOHLER®

GROUP 1-CRANKSHAFT
KS530-3002




ILLUSTRATIONS ARE REPRESENTATIVE - NOT INTENDED TO SHOW ALL DETAILS

GROUP 2-CRANKCASE
KS530-3002




ILLUSTRATIONS ARE REPRESENTATIVE - NOT INTENDED TO SHOW ALL DETAILS


GROUP 4-HEAD/VALVE BREATHER
KS530-3002




GROUP 5-IGNITION
KS530, KS540, KS590, KS595




GROUP 6-BLOWER HOUSING
KS530, KS540, KS590, KS595




GROUP 7-STARTER
KS530-3002




GROUP 8-FUEL SYSTEM
KS530-3002



GROUP 9-ENGINE CONTROLS
KS530-3002



GROUP 10-AIR INTAKE
KS530-3002



GROUP 11-EXHAUST
KS530-3002

